

- The results of the maintenance performed during that year, which may reveal that the current maintenance programme is not adequate.
- The results of the airworthiness review performed on the aircraft, which may reveal that the current maintenance programme is not adequate.
- Revisions introduced in the documents affecting the programme basis, such as the M.A.302(i) 'Minimum Inspection Programme' or the Design Approval Holder data.
- Applicable mandatory requirements for compliance with Part-21, such as Airworthiness Directives, Airworthiness Limitations, Certification Maintenance Requirements and specific maintenance requirements contained in the TCDS.

For the purpose of reviewing the results of the maintenance performed during that year, the airworthiness review staff should request the owner/CAMO to provide the records of all the maintenance performed during that year, including unscheduled maintenance.

When reviewing the results of the maintenance performed during that year and the results of the airworthiness review, attention should be paid as to whether the defects found may have been prevented by introducing in the maintenance programme certain recommendations from the Design Approval Holder which were initially disregarded by the owner.

AMC M.A.302(i) Aircraft maintenance programme

This AMC contains an acceptable 'Minimum Inspection Programme' for the following categories of ELA1 aircraft not involved in commercial operations:

- ELA1 aeroplanes;
- ELA1 sailplanes and ELA1 powered sailplanes; and
- ELA1 hot-air balloons.

Although this AMC does not contain an acceptable 'Minimum Inspection Programme' for gas balloons, the use of a 'Minimum Inspection Programme' is still possible as long as it complies with the requirements established in M.A.302(i).

The 'Minimum Inspection Programmes' defined in this AMC already comply with the requirements established in M.A.302(i) and may be used in order to define the basic information for the maintenance programme as required by M.A.302(h)2. However, the maintenance programme must be customised as required by M.A.302(h)3, which may be done by using the standard template contained in AMC M.A.302(e).

It must be noted that using the '1-month' tolerance permitted by M.A.302(i)1 for the annual inspection may result in an expired ARC.

Minimum Inspection Programme for ELA1 aeroplanes not involved in commercial operations

To be performed every annual/100 h interval, whichever comes first.

A tolerance of one month or 10 h may be applied. However, the next interval shall be calculated from the date/hours originally scheduled (without the tolerance).

Note 1: Use the manufacturer's maintenance manual to accomplish each task/inspection.

Note 2: Proper operation of backup or secondary systems and components should be included for every instance where a check is performed for improper installation/operation.

AMC/GM TO ANNEX I (PART-M) TO REGULATION (EU) No 1321/2014

SUBPART C — CONTINUING AIRWORTHINESS

ELA1 aeroplanes not involved in commercial operations	
System/component/area	Task & Inspection detail
GENERAL	
General	Remove or open all necessary inspection plates, access doors, fairings, and cowlings. Clean the aircraft and aircraft engine as required.
Lubrication/servicing	Lubricate and replenish fluids in accordance with the manufacturer's requirements.
Markings	Check that side and under-wing registration markings are correct. If applicable, check that an exemption for alternate display is approved. Identification plate for National Aviation Authority registered aircraft is present. Other identification markings on fuselage are in accordance with local (national) rules.
Weighing	Review weighing record to establish accuracy against installed equipment. Weigh the aircraft as required by the Part-NCO rules.
AIRFRAME	
Fabric and skin	Inspect for deterioration, distortion, other evidence of failure, and defective or insecure attachment of fittings. NOTE: When checking composite structures, check for signs of impact or pressure damage that may indicate underlying damage.
Fuselage structure	Check frames, formers, tubular structure, braces, and attachments. Inspect for signs of corrosion.
Systems and components	Inspect for improper installation, apparent defects, and unsatisfactory operation.
Pitot/static system	Inspect for security, damage, cleanliness, and condition. Drain any water from condensation drains.
General	Inspect for lack of cleanliness and loose equipment that might foul the controls.
Tow hooks	Inspect for condition of moving parts and wear. Check service life. Carry out operational test.

AMC/GM TO ANNEX I (PART-M) TO REGULATION (EU) No 1321/2014

SUBPART C — CONTINUING AIRWORTHINESS

CABIN AND COCKPIT	
Seats, safety belts and harnesses	Inspect for poor condition and apparent defects. Check for service life.
Windows, canopies and windshields	Inspect for deterioration and damage, and for function of emergency jettison.
Instrument panel assemblies	Inspect for poor condition, mounting, marking, and (where practicable) improper operation. Check markings of instruments in accordance with the Flight Manual.
Flight and engine controls	Inspect for improper installation and improper operation.
Speed/weight/manoeuvre placard	Check that the placard is correct and legible and accurately reflects the status of the aircraft.
All systems	Inspect for improper installation, poor general condition, apparent and obvious defects, and insecurity of attachment.
LANDING GEAR	
Shock-absorbing devices	Inspect for improper fluid level. Inspect for wear and deformation of rubber pads, bungees, and springs.
All units	Inspect for poor condition and insecurity of attachment.
Retracting and locking mechanism	Inspect for improper operation.
Linkages, trusses and members	Inspect for undue or excessive wear fatigue and distortion.
Hydraulic lines	Inspect for leakage. Check service life.
Electrical system	Inspect for chafing and improper operation of switches.
Wheels	Inspect for cracks, defects, and condition of bearings.
Tyres	Inspect for wear and cuts.

AMC/GM TO ANNEX I (PART-M) TO REGULATION (EU) No 1321/2014

SUBPART C — CONTINUING AIRWORTHINESS

Brakes	<p>Inspect for improper adjustment and wear.</p> <p>Carry out operational test.</p>
Floats and skis	Inspect for insecure attachment and apparent defects.
WING AND CENTRE SECTION	
All components	Inspect all components of the wing and centre section assembly for poor general condition, fabric or skin deterioration, distortion, evidence of failure, insecurity of attachment.
Connections	Inspect main connections (e.g. between wings, fuselage, wing tips) for proper fit, play within tolerances, wear or corrosion on bolts and bushings.
FLIGHT CONTROLS	
Control circuit/stops	Inspect control rods and cables. Check that the control stops are secure and make contact.
Control surfaces	<p>Inspect aileron, flap, elevator, air brake and rudder assemblies, hinges, control connections, springs/bungees, tapes and seals.</p> <p>Check and record range of movement and cable tensions, if specified, and check free play.</p>
Trim systems	<p>Inspect trim surfaces, controls, and connections.</p> <p>Check full range of motion.</p>
EMPENNAGE	
All components and systems	Inspect all components and systems that make up the complete empennage assembly for poor general condition, fabric or skin deterioration, distortion, evidence of failure, insecure attachment, improper component installation, and improper component operation.
AVIONICS AND ELECTRICS	
Batteries	Inspect for improper installation, improper charge and spillage and corrosion.
Radio and electronic equipment	<p>Inspect for improper installation and insecure mounting.</p> <p>Carry out ground function test.</p>

AMC/GM TO ANNEX I (PART-M) TO REGULATION (EU) No 1321/2014

SUBPART C — CONTINUING AIRWORTHINESS

Wiring and conduits	Inspect for improper routing, insecure mounting, and obvious defects.
Bonding and shielding	Inspect for improper installation, poor condition, and chafing and wear of insulation.
Antennas	Inspect for poor condition, insecure mounting, and improper operation.
POWERPLANT	
Engine section	Inspect for visual evidence of excessive oil, fuel or hydraulic leaks and sources of such leaks.
Studs and nuts	Inspect for looseness, signs of rotation and obvious defects.
Internal engine	Inspect for cylinder compression (record measures for each cylinder) and for metal particles or foreign matter in oil filter, screens and sump drain plugs. If there is weak cylinder compression, inspect for improper internal condition and improper internal tolerances.
Engine mounts	Inspect for cracks, looseness of mounting, and looseness of the engine to mount attachment.
Flexible vibration dampeners	Inspect for poor condition and deterioration.
Engine controls	Inspect for defects, improper travel, and improper safe tying.
Lines, hoses and clamps	Inspect for leaks, improper condition, and looseness.
Exhaust stacks	Inspect for cracks, defects, and improper attachment.
Turbocharger and intercooler	Inspect for leaks, improper condition, and looseness of connections and fittings.
Liquid cooling systems	Inspect for leaks and proper fluid level.
Electronic engine control	Inspect for signs of chafing and proper electronics and sensor installation.
Accessories	Inspect for apparent defects in security of mounting.
All systems	Inspect for improper installation, poor general condition, defects and insecure attachment.

AMC/GM TO ANNEX I (PART-M) TO REGULATION (EU) No 1321/2014

SUBPART C — CONTINUING AIRWORTHINESS

Cowling	Inspect for cracks and defects. Check cowling flaps.
Cooling baffles and seals	Inspect for defects, improper attachment, and wear.
Fuel tanks	Inspect for improper installation and connection.
CLUTCHES AND GEARBOXES	
Filters, screens, and chip detectors	Inspect for metal particles and foreign matter.
Exterior	Inspect for oil leaks.
Output shaft	Inspect for excessive bearing play and condition.
PROPELLER	
Propeller assembly	Inspect for cracks, nicks, binds, and oil leakage.
Propeller bolts	Inspect for proper installation, looseness, signs of rotation, and lack of safe tying.
Propeller control mechanism	Inspect for improper operation, insecure mounting, and restricted travel.
Anti-icing devices	Inspect for improper operation and obvious defects.
MISCELLANEOUS	
Ballistic rescue system	Inspect for proper installation, unbroken activation mechanism, proper securing while on ground, validity of inspection periods of pyrotechnic devices, and parachute packing intervals.
Other miscellaneous items	Inspect installed miscellaneous items that are not otherwise covered by this listing for improper installation and improper operation.
OPERATIONAL CHECKS	
Power and revolutions per minute (rpm)	Check that power output, static and idle rpm are within published limits.
Magnetos	Check for normal function.
Fuel and oil pressure	Check they are within normal values.

AMC/GM TO ANNEX I (PART-M) TO REGULATION (EU) No 1321/2014

SUBPART C — CONTINUING AIRWORTHINESS

Engine temperatures	Check they are within normal values.
Engine	For engines equipped with automated engine control (e.g. FADEC), perform the published run-up procedure and check for discrepancies.
Engine	For dry-sump engines and engines with turbochargers and for liquid cooled engines, check for signs of disturbed fluid circulation.
Pitot-static system	Perform operational check.
Transponder	Perform operational check.

Minimum Inspection Programme for ELA1 sailplanes and ELA1 powered sailplanes not involved in commercial operations

To be performed:

- every annual/100 h interval (for Touring Motor Gliders (TMG)), whichever comes first; or
- every annual interval (for other than TMGs).

A tolerance of one month or 10 h, as applicable, may be applied. However, the next interval shall be calculated from the date/hours originally scheduled (without the tolerance).

Note 1: Use the manufacturer's maintenance manual to accomplish each task/inspection.

Note 2: In the case of TMGs, it is acceptable to control the hours of use of the aircraft, engine and propeller as separate entities. Any maintenance check to be done between two consecutive annual/100 h inspections may be performed separately on the aircraft, engine and propeller depending on when each element reaches the corresponding hours. However, at the time of the annual/100 h inspection, all the elements must be covered.

Note 3: Proper operation of backup or secondary systems and components should be included for every instance where a check is performed for improper installation/operation.

AMC/GM TO ANNEX I (PART-M) TO REGULATION (EU) No 1321/2014

SUBPART C — CONTINUING AIRWORTHINESS

ELA1 sailplanes and ELA1 powered sailplanes not involved in commercial operations	
System/component/area	Task & Inspection detail
GENERAL	
General — all tasks	The aircraft must be clean prior to inspection. Inspect for security, damage, wear, integrity, drain/vent holes clear, signs of overheating, leaks, chafing, cleanliness and condition as appropriate to the particular task. Whilst checking composite structures, check for signs of impact or pressure damage that may indicate underlying damage.
Lubrication/servicing	Lubricate and replenish fluids in accordance with the manufacturer’s requirements.
Markings	Check that side and under-wing registration markings are correct. If applicable, check that an exemption for alternate display is approved. Identification plate for National Aviation Authority registered aircraft is present. Other identification markings on fuselage in accordance with local (national) rules.
Weighing:	Review weighing record to establish accuracy against installed equipment. Weigh the aircraft as required by the Part-NCO rules.
AIRFRAME	
Fuselage paint/gel coat, including registration markings	Inspect external surface and fairings, gel coat, fabric covering or metal skin, and paintwork. Check that registration marks are correctly applied.
Fuselage structure	Check frames, formers, tubular structure, skin, and attachments. Inspect for signs of corrosion on tubular framework.
Nose fairing	Inspect for evidence of impact with ground or objects.
Release hook(s)	Inspect nose and Centre of Gravity (C of G) release hooks and controls. Check operational life. Carry out operational test. If more than one release hook or control is fitted, check operation of all release hooks from all positions.
Pot pitot/ventilator	Check alignment of probe, check operation of ventilator.
Pitot/static system	Inspect pitot probes, static ports and all accessible tubing for security, damage, cleanliness, and condition. Drain any water from condensation drains.
Bonding/vents drains	Check all bonding leads and straps. Check that all vents and drains are clear from debris.

AMC/GM TO ANNEX I (PART-M) TO REGULATION (EU) No 1321/2014

SUBPART C — CONTINUING AIRWORTHINESS

CABIN AND COCKPIT	
Cleanliness/loose articles	Check under cockpit floor/seat pan and in rear fuselage for debris and foreign items.
Canopy, locks and jettison	Inspect canopy, canopy frame and transparencies for cracks, unacceptable distortion, and discolouration. Check operation of all locks and catches. Carry out an operational test of the canopy jettison system from all positions.
Seat/cockpit floor	Inspect seat(s). Check that all loose cushions are correctly installed and, as appropriate, energy absorbing foam cushions are fitted correctly. Ensure that all seat adjusters fit and lock correctly.
Harness(es)	Inspect all harnesses for condition and wear of all fastenings, webbing, and fittings. Check operation of release and adjustments.
Rudder pedal assemblies	Inspect rudder pedal assemblies and adjusters.
Flight control circuits/stops	Inspect flight controls rods/cables. Check that control stops are secure and make contact. Pay particular attention to wear and security of liners and cables in 'S' tubes. Inspect self-connecting control devices.
Instrument panel assemblies	Inspect instrument panel and all instruments/equipment. Check instrument readings are consistent with ambient conditions. Check marking of all switches, circuit breakers, and fuses. Check operation of all installed equipment, as possible, in accordance with the manufacturer's instructions. Check markings of instruments in accordance with the Flight Manual.
Oxygen system	Inspect oxygen system. Check bottle hydrostatic test date expiry in accordance with the manufacturer's recommendations. Ensure that the bottle is not completely empty (13,8 bars/200 psi minimum) and refill with aviator's oxygen only. Clean masks and regulators with suitable cleaning wipes. Ensure that the oxygen installation is recorded on weight and C of G schedule. CAUTION: OBSERVE ALL SAFETY PRECAUTIONS.
Colour-coding of controls	Ensure that controls are colour-coded and in good condition, as follows: Tow release: yellow Air Brakes: blue Trimmer: green Canopy normal operation: white Canopy jettison: red Other controls: clearly marked but not using any of the above colours.
Equipment stowed in centre section	Check for security and condition. Check validity of any safety equipment. Check the manufacturer's and the NAA's (if required) data plates.
Speed/weight/ manoeuvre placard	Check that the placard is correct and legible and accurately reflects the status of the aircraft.

AMC/GM TO ANNEX I (PART-M) TO REGULATION (EU) No 1321/2014

SUBPART C — CONTINUING AIRWORTHINESS

LANDING GEAR	
Front skid/nose wheel and mounts	Inspect for evidence of hard/heavy landings. Check skid wear. Inspect wheel, tyre, and wheel box. Check tyre pressure.
Main wheel and brake assembly	Check for integrity of hydraulic seals and leaks in pipe work. Check life of hydraulic hoses and components if specified by the manufacturer. Remove brake drums, check brake lining wear. Check disk/drum wear. Refit drum. Check brake adjustment. CAUTION: BRAKE DUST MAY CONTAIN ASBESTOS. Check operation of brake. Check level of brake fluid and replenish if necessary. Check tyre pressure. CAUTION: CHECK TYPE OF BRAKE FLUID USED AND OBSERVE SAFETY PRECAUTIONS.
Undercarriage suspension	Check springs, bungees, shock absorbers, and attachments. Check for signs of damage. Service strut if applicable.
Undercarriage retract system and doors	Check retraction mechanism and controls, warning system if fitted, gas struts, doors and linkages/springs, over-centre/locking device. Perform retraction test.
Tail skid/wheel	Inspect for evidence of hard/heavy landings. Check skid wear. Inspect wheel, tyre, and wheel box. Check bond of bonded skids. Check tyre pressure.
Wheel brake control circuit	Inspect wheel brake control rods/cables. If combined with air brake, ensure correct rigging relationship. Check parking brake operation if fitted.
WING AND CENTRE SECTION	
Centre section fairing	Inspect for security, damage, and condition.
Wing attachments	Inspect the wing structural attachments. Check for damage, wear, and security. Check for rigging damage. Check condition of wing attachment pins.
Aileron control circuit/stops	Inspect aileron control rods/cables. Check that control stops are secure and make contact. Inspect self-connecting control devices.
Air brake control circuit	Inspect air brake control rods/cables. Check friction/locking device (if fitted). Inspect self-connecting control devices.
Wing struts/wires	Inspect wing struts for damage and internal corrosion. Re-inhibit wing struts internally every three years or in accordance with the manufacturer's instructions.
Wings including underside registration markings	Check mainplane structure externally and internally as far as possible. Check gel coat, fabric covering, or metal skin. Check that registration marks are correctly applied.
Ailerons and controls	Inspect aileron and flaperon assemblies, hinges, control connections, springs/bungees, tapes, and seals. Ensure that seals do not impair full range of movement.

AMC/GM TO ANNEX I (PART-M) TO REGULATION (EU) No 1321/2014

SUBPART C — CONTINUING AIRWORTHINESS

Air brakes/spoilers	Inspect air brake/spoiler panel(s) operating rods, closure springs, and friction devices as fitted.
Flaps	Check flap system and control. Inspect self-connecting control devices.
Control deflections and free play, and record on worksheets	Check and record range of movements and cable tensions, if specified, and check free play.
EMPENNAGE	
Tailplane and elevator	With tailplane de-rigged, check tailplane and attachments, self-connecting and manual control connections. Check gel coat, fabric covering, or metal skin.
Rudder	Check rudder assembly, hinges, attachments, balance weights.
Rudder control circuit/stops	Inspect rudder control rods/cables. Check that control stops are secure and make contact. Pay particular attention to wear and security of liners and cables in 'S' tubes.
Elevator control circuit/stops	Inspect elevator control rods/cables. Check that control stops are secure and make contact. Inspect self-connecting control devices.
Trimmer control circuit	Inspect trimmer control rods/cables. Check friction/locking device.
Control deflections and free play, and record on worksheets	Check and record range of movements and cable tensions, if specified, and check free play.
AVIONICS AND ELECTRICS	
Electrical installation/fuses	Check all electrical wiring for condition. Check for signs of overheating and poor connections. Check fuses/trips for condition and correct rating.
Battery security and corrosion	Check battery mounting for security and operation of clamp. Check for evidence of electrolyte spillage and corrosion. Check that the battery has the main fuse fitted correctly. It is recommended to carry out battery capacity test on gliders equipped with radio, used for cross-country, controlled airspace, or competition flying.
Radio installations and placards	Check radio installation, microphones, speakers and intercom, if fitted. Check that the call sign placard is installed. Carry out ground function test. Record radio type fitted.
Altimeter datum	Check barometric sub-scale. Maximum error 2 Mb.
Pitot-static system	Perform operational check.

AMC/GM TO ANNEX I (PART-M) TO REGULATION (EU) No 1321/2014

SUBPART C — CONTINUING AIRWORTHINESS

Transponder	Perform operational check.
MISCELLANEOUS	
Removable ballast	Check removable ballast mountings and securing devices (including fin ballast if applicable) for condition. Check that ballast weights are painted with conspicuous colour. Check that provision is made for the ballast on the loading placard.
Drag chute and controls	Inspect chute, packing and release mechanism. Check packing intervals.
Water ballast system	Check water ballast system, wing and tail tanks as fitted. Check filling points, level indicators, vents, dump and frost drains for operation and leakage. If loose bladders are used, check for leakage and expiry date as applicable.
POWERPLANT (when applicable)	
Engine pylons and mountings	Inspect engine and pylon installation. Check engine compartment and fire sealing.
Gas strut	Check gas strut.
Pylon/engine stops	Check limit stops on retractable pylons. Check restraint cables.
Electric actuator	Inspect electric actuator, motor, spindle drive, and mountings.
Electrical wiring	Inspect all electrical wiring. Pay special attention to wiring that is subject to bending during extension and retraction of engine/pylon.
Limit switches	Check operation of all limit switches and strike plates. Make sure that they are not damaged by impact.
Fuel tank(s)	Check fuel tank mountings and tank integrity. Check fuel quantity indication system if fitted.
Fuel pipes and vents	Check all fuel pipes especially those subject to bending during extension and retraction of engine/pylon. Check that vents are clear. Make sure that overboard drains do not drain into engine compartment. Check self-sealing.
Fuel cock or shut off valve	Check operation of fuel cock or shut-off valve and indications.
Fuel pumps and filters	Clean or replace filters as recommended by the manufacturer. Check operation of fuel pumps for engine supply or tank replenishment. Check fuel pump controls and indications.
Decompression valve	Inspect decompression valve and operating control.

AMC/GM TO ANNEX I (PART-M) TO REGULATION (EU) No 1321/2014

SUBPART C — CONTINUING AIRWORTHINESS

Spark plugs	Carry out spark plug service. It is recommended to replace spark plugs at annual intervals.
Harnesses and Magneto	Inspect low-tension and high-tension wiring, connectors, spark plug caps. Check magneto to engine timing. Check impulse coupling operation.
Propeller bolts, assembly, mounting, torquing & drive belt	Inspect propeller, hub, folding mechanism, brake, pitch change mechanism, stow sensors.
Doors	Check engine compartment doors, operating cables, rods, and cams.
Safety springs	Check all safety and counterbalance springs.
Extension and retraction	Check that extension and retraction operation times are within limits specified by manufacturer. Check light indications and interlocks for correct operation.
Exhaust	Inspect exhaust system, silencer, shock mounts, and links.
Engine installation	Inspect engine and all accessories. Carry out compression test and record results. Compression test results: No1 (left/front): No2 (right/rear):
Lubrication	Change engine oil and filter. Replenish oil and additive tanks.
Engine instruments	Inspect all engine instruments and controls. Check control unit, mounts, bonding and connections. Carry out internal self-test if fitted.
Flexible vibration dampers	Check for poor condition and deterioration.
Engine battery	If separate from airframe battery, inspect battery and mountings. If the main fuse is fitted, check rating and condition. Perform a functional test.
Placards	Check that all placards are in accordance with flight manual and legible.
Oil and fuel leaks	With the engine fully serviced, check the fuel and oil system for leaks.

Minimum Inspection Programme for ELA1 hot-air balloons not involved in commercial operations

To be performed every annual interval.

A tolerance of one month may be applied. However, the next interval shall be calculated from the date originally scheduled (without the tolerance).

Note 1: Use the manufacturer's maintenance manual to accomplish each task/inspection.

AMC/GM TO ANNEX I (PART-M) TO REGULATION (EU) No 1321/2014

SUBPART C — CONTINUING AIRWORTHINESS

Note 2: Proper operation of backup or secondary systems and components should be included for every instance where a check is performed for improper installation/operation.

1. Envelope

System/component/area	Task & Inspection detail
Identification (type/serial number/registration plate)	Check for presence and verify type/serial number installed.
Crown ring and line	In place; not corroded; crown line undamaged and has appropriate length.
Vertical/horizontal load tapes	Check joints with the crown ring, top of the envelope and wires. All load tapes undamaged along their entire length. Inspect base horizontal tape and edge of the envelope top. Inspect joint between base horizontal load tape and vertical load tapes.
Envelope fabric	<p>Inspect the envelope fabric panels (including parachute and rotation vents if fitted) for damage, porosity overheating or weakness. Unrepaired damage is within tolerance given by the manufacturer.</p> <p>If substantial fabric porosity is suspected, then a flight test should be performed, but only after a grab test has demonstrated that the balloon is safe to fly.</p> <p>Perform grab test in accordance with the manufacturer's instructions.</p>
Flying cables	<p>Inspect for damage (particularly heat damage).</p> <p>Kevlar cable — yellow core is not visible</p>
Karabiners	Inspect for damage. Karabiner lock is working properly.
Melting link and Tempilabel	Check maximum temperature indication (flag/'tell-tale').
Control system lines	<p>Inspect for damage wear, security of knots.</p> <p>Check proper length. Check lines attachments for damage, wear, security.</p>
Control lines and their attachments	Inspect for damage, wear, security of knots. Check proper length of the lines.
Envelope pulleys	Inspect for damage, wear, free running, contamination, security of attachment.

2. Burner

System/component/area	Task & Inspection detail
Identification (type/serial number)	Check for presence and verify type/serial number installed.
Burner frame	Inspect welds for cracking.
	Inspect tubes for distortion/deformation/cuts/gouges.
	Inspect frame for security of fasteners (heat shields, flexi-corners).
	Inspect frame lugs for wear, cracking.
	Inspect general condition (corrosion, heat shields).
Gimballing	Check stiffness, security of fitting manifolds.
Leak check	Perform leak check of the burner.
Hoses	Inspect all hoses for wear, damage, leak, and lifetime limitation. Inspect condition and correct function of the fuel.
Pressure gauges	Check Pressure gauge reads zero when no pressure applied, lens present.
Pilot valves/flame	Check Shut off, free movement, correct function, lubricate if necessary.
Whisper valves/flame	Check Shut off, free movement, correct function, lubricate if necessary.
Main valves/flame	Check Shut off, free movement, correct function, lubricate if necessary.
Coils	Check for damage, distortion, security of fasteners. Inspect welds for cracking.
	Check security of jets, tighten or replace as necessary.
Fuel	Check correct type, check dates (if applicable).

3. Basket

System/component/area	Task & Inspection detail
Identification (type/serial number)	Check for presence and verify type/serial number installed.
Basket body	Check the general condition of the basket body. Inspect weave for damage, cracks/holes. No sharp objects inside the basket.
Basket wires	Inspect for damage, check eye rings.
Karabiners	Inspect for damage. Karabiner lock is working properly.
Basket floor	Inspect for damage and cracks.
Runners	Inspect for damage.
Rawhide	Inspect for damage, wear and attachments to the floor.
Rope handles	Inspect for damage, security of attachment.
Cylinder straps	Inspect for damage, deterioration.
Padded basket edge trim	Inspect for damage and wear.
Burner rods	Inspect for damage, wear and cracking.
Padded burner rod covers	Inspect for damage and wear.
Basket equipment	Check presence and functionality.
Pilot restraint	Inspect for security and condition.
Fire extinguisher	Check expiration date and protection cover.
First-aid kit	Check for completeness and expiration date.

4. Fuel tanks

System/component/area	Task & Inspection detail
Identification (type/serial number)	Check for presence.
Cylinder	Check periodic inspections for each cylinder is valid (date) (e.g. 10 years' inspection).
Cylinder body	Inspect for damage, corrosion.
Liquid valve	Inspect for damage, corrosion, correct operation.
	Inspect O-ring seals, lubricate/replace as required.
Fixed liquid Level gauge	Inspect for damage, corrosion, correct operation.
Contents Gauge	Inspect for damage, corrosion, freedom of movement.
Vapour valve	Inspect for damage, corrosion, correct operation (including regulator).
	Inspect Quick Release Coupling for correct operation, sealing.
Padded cover	Inspect for damage.
Pressure relief valve	Does not indicate over pressuring
Assembly	Inspect, leak-test all pressure holding joints using leak detector.
	Functional test

5. Additional equipment

System/component/area	Task & Inspection detail
Instruments	Functional check
Quick release	Functional check and inspect the condition of the latch, bridle and ropes for wear and deterioration. Check that the karabiners are undamaged and operate correctly.
Communication/navigation equipment (radio)	Perform operational check.
Transponder	Perform operational check.

AMC M.A.304 Data for modifications and repairs

A person or organisation repairing an aircraft or component should assess the damage against published approved repair data and the action to be taken if the damage is beyond the limits or outside the scope of such data. This could involve any one or more of the following options; repair by replacement of damaged parts, requesting technical support from the type certificate holder or from an organisation approved in accordance with Part-21 and finally Agency approval of the particular repair data

AMC M.A.305(d) Aircraft continuing airworthiness record system

The current status of AD should identify the applicable AD including revision or amendment numbers. Where an AD is generally applicable to the aircraft or component type but is not applicable to the particular aircraft or component, then this should be identified. The AD status includes the date when the AD was accomplished, and where the AD is controlled by flight hours or flight cycles it should include the aircraft or engine or component total flight hours or cycles, as appropriate. For repetitive ADs, only the last application should be recorded in the AD status. The status should also specify which part of a multi-part directive has been accomplished and the method, where a choice is available in the AD.

The status of current modification and repairs means a list of embodied modification and repairs together with the substantiating data supporting compliance with the airworthiness requirements. This can be in the form of a Supplemental Type Certificate (STC), SB, Structural Repair Manual (SRM) or similar approved document.

The substantiating data may include:

- (a) compliance programme; and
- (b) master drawing or drawing list, production drawings, and installation instructions; and
- (c) engineering reports (static strength, fatigue, damage tolerance, fault analysis, etc.); and
- (d) ground and flight test programme and results; and
- (e) mass and balance change data; and
- (f) maintenance and repair manual supplements; and
- (g) maintenance programme changes and instructions for continuing airworthiness; and
- (h) aircraft flight manual supplement.